



CONVEX MIRROR

PART# F1-001

INSTALLATION INSTRUCTIONS

Included in this Kit



Convex Mirror &
Hardware

STEP 1

Insert T-bolts into front roof track and turn clockwise to hold into place.



STEP 2

Attach mounting arms to mirror as shown using the threaded knobs.



STEP 3

Secure mirror to the track T-bolts using supplied nuts. Before fully tightening, center mirror between struts and retighten with a 13mm socket.

Adjust mirror angle by loosening threaded knobs and re-tighten when finished.



INSTALLATION COMPLETE



For more instructions and videos visit sierralsv.com